

Packing instructions Aerodyne 2.1 Semi-Stowless Main Deployment Bag

1.



The Aerodyne 2.1 Semi-Stowless Main Deployment bag will come with 3 or 4 grommet locking stows and can be identified by the black webbing magnetic tuck tab pocket fitted with center safety stow.

2.



Insert canopy into the main deployment bag. Starting with the center, route the large packing rubber bands through the corresponding grommet and secure line bite approximately 1.5-2" inches in length using the double stow method.

3.



Center locking stows are to be made before moving along to the outer locking stows. All locking stows are to be free and clear of each other.

4.



Route the excess suspension line over top of bag down to the bottom of line stow pocket.
****Excess Suspension line is to enter (begin) and exit (end) in center notch of line stow pocket.**

5.



Continue figure 8 line placement into magnetic line stow pocket, ensuring line stows are as wide as line stow pocket.

6.



Push suspension line down into the center of the magnetic line stow pocket, placing lines along the bottom of pocket and into the pocket corners. Leave 18-22 inches (45-55cm) of excess suspension line between main deployment bag and connector links.

7.



Close magnetic line stow pocket by inserting magnetic tuck tabs into their magnetic pockets underneath black webbing.
****Excess Suspension line is to enter (begin) and exit (end) in center notch of line stow pocket.**

8.



Double stow the center closing stow. The Aerodyne 2.1 Semi-Stowless Main Deployment bag is now closed and ready to be placed into harness container main tray.